

# INSTALLATION INSTRUCTION

4013\_V2



**1.** Tuck the two anchors to backseat.



**2.** Insert four headrests.



**3.** Insert 3 anchors into the window track.